



Application Note 6

Standalone eMix on Windows NT

Product:	System 5 Software	Software Version:	eMix 2.5 and higher
Audience:	All	Document Revision:	1.2
Subassembly:	eMix Application	Date:	July, 2002

System Requirements

- 350 MHz or faster processor
- 256 MB RAM
- 5 GB hard drive or larger
- 1024 x 768 display resolution with 16-bit color depth
- Windows NT 4.0 Service Pack 6
- Internet Explorer 5.5 Service Pack 2

eMix does not presently support Windows 98, 2000, or XP.

System 5 eMix version 2.0 or higher can be run as a standalone application on a Windows NT computer by setting up a network loopback adapter:

1. From the Desktop or Windows Explorer, right-click on **Network Neighborhood** and select **Properties**.
2. Click the **Adapters** tab.
3. Click **Add**.
4. Select **MS Loopback Adapter**.
5. Click **OK** and follow the Windows instructions for driver installation.
6. In the next dialog that appears, specify the **IP Address** (192.168.0.1) and **Subnet Mask** (255.255.255.0).
7. Click **OK**.

Windows will restart.

8. Double-click the **MMPass** icon on your desktop to enable your Mixer Model.
9. Start eMix.